

MODEL  
DSC-23



**DELUXE 2 SLICE TOASTER**  
**MAKES CHARACTER IMAGES ON TOAST**



# IMPORTANT SAFEGUARDS

When using electrical appliances especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. READ ALL INSTRUCTIONS.
2. Do not touch hot surfaces. Use any handles or knobs.
3. To protect against electrical shock, do not place cord, plug or appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool completely before moving, putting on or taking off parts, or before cleaning.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil, water or other hot liquids.
12. Do not use appliance for other than intended use.
13. Do not insert oversized foods, metal foil packages, utensils or the plug and power cord in the toast slots as this may create a risk of fire or electric shock.
14. A fire may occur if toaster is covered or touching flammable material, including curtains, draperies, walls, overhead cabinets, paper or plastic products, cloth towels, and the like, when in operation.
15. Do not attempt to dislodge food when toaster is plugged in.
16. Do not operate toaster while unattended.
17. Before unplugging toaster, make sure toast lever / lifter is in the “up” position.
18. Do not cook, warm or toast rice cakes, fried foods, or non-bread items.

19. Do not clean with metal scouring pads. Pieces can break off the pad and contact electrical parts, resulting in risk of electrical shock.
20. Failure to clean crumb tray may result in a fire hazard.

**SAVE THESE INSTRUCTIONS**

## 2 SLICE TOASTER FEATURES



1 Extra Wide Toasting Slots

2 High-Rise Toast Lift

3 Toast Cancel Button

4 Bagel Function Button

5 Frozen Function Button

6 Adjustable Browning Dial

7 Removable Crumb Tray

This appliance is for HOUSEHOLD USE ONLY. It may be plugged into an AC electrical outlet (ordinary household current). Do not use any other electrical outlet.

DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

A short power-supply cord (or detachable power-supply cord) is to be provided to reduce the risk resulting from becoming entangled in or tripping over a longer cord. Longer extension cords are available and may be used if care is exercised in their use. If an extension cord is used,

1. The marked electrical rating of the extension cord should be at least as great as the electrical rating of the appliance, and
2. The cord should be arranged so that it will not drape over the countertop or tabletop where it can be pulled on by children or tripped over unintentionally.

### **POLARIZED PLUG**

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit into the outlet, reverse the plug and try again. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

### **LINE CORD SAFETY TIPS**

1. Never pull or yank on cord or the appliance.
2. To insert plug, grasp it firmly and guide it into outlet.
3. To disconnect appliance, grasp plug and remove it from outlet.
4. Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced.
5. Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.

## **BEFORE FIRST USE**

### **IMPORTANT**

During the first few minutes of initial use, you may notice smoke and/or a slight odor. This is normal and should quickly disappear. It will not recur after appliance has been used a few more times.

For your safety, always read and understand the Use and Care Manual before attempting to use any electric appliance.

#### **BEFORE USING:**

1. Carefully unpack the toaster. Remove all packaging materials, including those which may be inside the toasting slots.
2. Wipe exterior surfaces of the base with a soft, moist cloth to remove dust particles collected during packing and handling. Dry thoroughly. Do not use abrasive cleaners. NEVER IMMERSE THE TOASTER, CORD OR PLUG IN WATER OR ANY OTHER LIQUID.
3. Be sure the crumb tray is pushed all the way into the toaster.
4. Your toaster is now ready to use.

Solid surface countertops can be easily scratched, cracked, scorched, or damaged, especially when exposed to heat. To prevent damage, the following precautions should be observed when using this product:

- Always use a trivet under heat generating sources such as Toasters.

## **OPERATING INSTRUCTIONS**

1. Plug the cord into a 120 volt, 60 HZ AC outlet. Position toaster at least 3 inches away from wall or rear of counter.
2. Let the first toasting process take place without inserting any bread to preheat the new elements and burn off any residue.
3. Select the desired level of darkness by turning the "1-6" light/dark knob on the front panel of the toaster to the right for darker toast and to the left for lighter toast. Your selection should vary based on the moisture content, thickness of bread, whether fresh or frozen and your darkness preference.
4. Next, place bread in slot and depress bread carriage lever downwards until it locks. Carriage lever will not stay down if toaster is not plugged in. The self-adjusting bread guides will automatically center the bread for browning. If using the FROZEN or BAGEL function buttons, press the selected button at this time.  
NOTE: During Bagel function both sides will toast to the shade selected. Bagel function warms outside of bagel while toasting cut side.

**IMPORTANT:** If using BAGEL function, ensure the cut side of the bagel faces the interior heating element of the toaster.

5. After the desired level of darkness has been reached, the bread will pop up automatically and is ready for removal from the slots. The bread carriage will return to its original position and disconnect the elements, ready for the next toasting.
6. To remove toast, press up on the bread carriage lever to lift toast out of the bread slots. NOTE: To remove jammed toast, unplug toaster and remove bread once toaster has cooled down. Never insert fingers or metallic utensils into slots. IMPORTANT: To stop or interrupt any toasting cycle, press CANCEL button. Bread will pop up and toaster will turn off. NEVER force the carriage up manually to cancel. This may cause damage to the toaster.

**DO NOT WRAP THE CORD AROUND THE MAIN BODY OF APPLIANCE DURING OR AFTER USE.**

**CAUTION:** Due to possible risk of fire, **DO NOT** cook toaster pastries in this toaster. Use a toaster oven instead.

If a toaster must be used:

- **NEVER** use cracked or broken toaster pastries.
- **NEVER** leave the toaster unattended.
- **ALWAYS** use the lightest toast setting.
- The toaster should **NEVER** be operated by children. Fillings will become hot and may cause burns.

## CLEANING AND STORAGE

This appliance requires little maintenance. It contains no user-serviceable parts. Do not attempt to repair it yourself. Any servicing that requires disassembly, other than cleaning, must be performed by a qualified appliance repair technician.

### TO CLEAN:

Be sure the toaster is unplugged before cleaning.

**NOTE:** If the toaster is used daily, it is recommended that the crumb tray be cleaned weekly.

Wipe the toaster exterior with a clean, damp cloth. Do not use abrasive cleaners. Do not put cord or plug in water or other liquids.

**CRUMB TRAY:** To prevent electric shock, be sure the toaster is unplugged from the wall outlet. Before opening the crumb tray, make sure the toaster has completely cooled following use. Open the hinged crumb tray by squeezing the latch and then pull the crumb tray away from the bottom of the toaster. Discard the crumbs over a sink or garbage can and wipe tray with a clean cloth. Close the crumb tray,









