



MODEL DTS-502

SLOW COOKER SET

Distributed by Select Brands, Inc. Lenexa, KS 66219

IMPORTANT SAFEGUARDS

When using electrical appliances especially when children are present, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

1. READ ALL INSTRUCTIONS.
2. Do not touch hot surfaces. Use any handles or knobs. Use potholders when removing cover or handling hot containers.
3. To protect against electrical shock, do not place cord, plug or appliance in water or other liquid.
4. Close supervision is necessary when any appliance is used by or near children.
5. Unplug from outlet when not in use and before cleaning. Allow to cool before putting on or taking off parts and before cleaning.
6. Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner. Return appliance to the nearest authorized service facility for examination, repair or adjustment.
7. The use of accessory attachments not recommended by the appliance manufacturer may cause injury.
8. Do not use outdoors.
9. Do not let cord hang over edge of table or counter or touch hot surfaces.
10. Do not place on or near a hot gas or electric burner, or in a heated oven.
11. Extreme caution must be used when moving an appliance containing hot oil, water or other hot liquids.
12. Do not use appliance for other than intended use.
13. Lift and open cover carefully to avoid scalding, and allow water to drip into unit.
14. To disconnect, turn control to Off, then remove plug from wall outlet.
15. Removable insert is designed for use with this appliance only. It must never be used on a range top. Do not set a hot container on a wet or cold surface. Do not use a cracked container.
16. This product is intended for counter top use only.
17. **WARNING:** Spilled food can cause serious burns. Keep appliance and cord away from children. Never drape cord over edge of counter, never use outlet below counter, and never use with an extension cord.
18. **CAUTION:** TO PREVENT DAMAGE OR SHOCK HAZARD NEVER COOK DIRECTLY IN THE HEATING SURFACE OF THE SLOW COOKER. COOK ONLY IN THE CONTAINER PROVIDED.
19. FOR HOUSEHOLD USE ONLY.

SAVE THESE INSTRUCTIONS



OPERATING INSTRUCTIONS

PRODUCT MAY VARY SLIGHTLY FROM ILLUSTRATIONS

5 QT OVAL SLOW COOKER & 20 OZ DIPPER FEATURES



1 Glass Lid with Icon Handle

4 5 Quart Oval Base

7 Glass Lid with Icon Handle

2 Removable Stoneware Insert

5 Adjustable Temperature Dial

8 Removable Stoneware Insert

3 Cool-Touch Handles

6 Non-Skid Rubber Feet

9 20 Ounce Round Base

This appliance is for HOUSEHOLD USE ONLY. It may be plugged into an AC electrical outlet (ordinary household current). Do not use any other electrical outlet.

CORD PLUG

This appliance has a polarized plug (one blade is wider than the other). To reduce the risk of electric shock, this plug is intended to fit into a polarized outlet only one way. If the plug does not fit into the outlet, reverse the plug and try again. If it still does not fit, contact a qualified electrician. Do not attempt to modify the plug in any way.

SHORT POWER CORD

A short power-supply cord is used to reduce the risk resulting from it being grabbed by children, becoming entangled in, or tripping over a longer cord.

LINE CORD SAFETY TIPS

1. Never pull or yank on cord or the appliance.
2. To insert plug, grasp it firmly and guide it into outlet.
3. To disconnect appliance, grasp plug and remove it from outlet.
4. Before each use, inspect the line cord for cuts and/or abrasion marks. If any are found, this indicates that the appliance should be serviced and the line cord replaced.
5. Never wrap the cord tightly around the appliance, as this could place undue stress on the cord where it enters the appliance and cause it to fray and break.

DO NOT OPERATE APPLIANCE IF THE LINE CORD SHOWS ANY DAMAGE, OR IF APPLIANCE WORKS INTERMITTENTLY OR STOPS WORKING ENTIRELY.

IMPORTANT

During the first few minutes of initial use, you may notice smoke and/or a slight odor. This is normal and should quickly disappear. It will not recur after appliance has been used a few more times.

BEFORE USING

THIS PRODUCT IS NOT A TOY. IT IS NOT INTENDED TO BE USED BY CHILDREN. For your safety, always read and understand the Use and Care Manual before attempting to use any electrical appliance.

Solid surface counter tops can be easily scratched, cracked, scorched, or damaged, especially when exposed to heat. To prevent damage, the following precautions should be observed when using this product:

- Always use a heat-resistant trivet under heat generating sources such as Slow Cookers.
 - Do not place hot pans, pots, ceramic or stoneware inserts directly on the countertop surface.
 - Slow cooker stoneware inserts have a rough bottom. To avoid scratching surfaces, always place the stoneware insert on a heat resistant place mat or trivet.
1. Carefully unpack the slow cooker.
 2. Wash stoneware insert and glass lid in warm, soapy water. Rinse well and dry thoroughly.
 3. Wipe interior and exterior surfaces of the base with a soft, moist cloth to remove dust particles collected during packing and handling. **NEVER IMMERSER THE BASE, CORD OR PLUG IN WATER OR ANY OTHER LIQUID.**
 4. Slow cooker should be operated before initial use. After cleaning unit, place cooking pot inside the base. Pour 2 cups of water into the stoneware insert and cover with lid. Plug slow cooker into electrical wall outlet and turn to HIGH setting. Allow to operate approximately 20 minutes.
 5. After 20 minutes, switch OFF and unplug. Allow unit to cool. Remove stoneware insert, and discard water. Rinse the stoneware insert, dry thoroughly and replace it in the base.

STONEWARE INSERT

Like any ceramic, the stoneware insert may crack or break if not properly handled.

Failure to follow these instructions can cause breakage resulting in injury or property damage.

- All stoneware is breakable. Handle with care.
- **ALWAYS USE POT HOLDERS WHEN HANDLING HOT STONEWARE.**
- **DO NOT** place hot stoneware on counter. Use protective trivet.
- **DO NOT** place stoneware insert on any range top burner, under a broiler, microwave browning element, or in a toaster oven.
- **DO NOT** strike utensils against rim to dislodge food.
- **DO NOT** use stoneware insert to pop corn, caramelize sugar, or make candy.
- **DO NOT** use abrasive cleaners, scouring pads, or any object that will scratch the stoneware, other parts or accessories.
- **DO NOT** use or repair any item that is chipped, cracked, or broken.
- Bottom of stoneware insert may be rough. To avoid scratching surfaces, place on heat-resistant place mat, tablecloth, or trivet.
- **DO NOT** use stoneware insert for reheating foods or for general food storage.
- Always place foods into the stoneware insert when it is at room temperature; then place stoneware insert into cooking base before turning it on.
- Ingredients for a particular dish may be prepared in advance and stored in the stoneware insert in the refrigerator until ready to cook. **DO NOT** preheat cooking base before adding stoneware insert. **NEVER** heat the stoneware insert when it is empty.

USE: The stoneware insert can be used in conventional, convection and microwave ovens, in the refrigerator and in the dishwasher. It should be used in these applications without the glass lid.

CARE: Use only wooden, nylon, or plastic utensils. Metal utensils can scratch or leave gray marks. Stoneware insert may be washed by hand or in a dishwasher. Load carefully to avoid stoneware-to-stoneware contact and bumping against other items during the wash cycle.

DO NOT allow stoneware insert to soak or stand in water for an extended period of time. Applied heat after soaking may cause glaze crazing. If scouring is necessary, use only plastic or nylon cleaning pads with nonabrasive cleaners.

- Never subject the stoneware insert to sudden changes in temperature. **NEVER** place it where

it can come in contact with direct heat (e.g., on top of a range or under a broiler).

- When removing the stoneware insert from a microwave, be sure to use pot holders or oven mitts.
- Always use pot holders or oven mitts when removing stoneware insert from cooking base. Do not set stoneware insert directly on counter top or table; use a trivet or hot pad.
- Unplug slow cooker and allow to cool after use. Do not pour cold water into hot stoneware insert.

CARE OF GLASS COVER:

To prevent cracking or breaking of the glass cover, which may cause personal injury, cover should be treated with special care.

CAUTIONS: Glass cover may shatter if it is exposed to direct heat or subjected to severe temperature changes. Chips, cracks or deep scratches may also weaken the cover.

- **KEEP GLASS COVER AWAY FROM** broiler, microwave oven, hot stovetop burners, oven heat vents. If cover has been utilized in any of these locations, do not use it again, even if there are no signs of damage. Order a replacement cover immediately.
- **IF COVER BECOMES CHIPPED, CRACKED OR SCRATCHED, DO NOT USE IT.** Discard it and order a replacement.
- **ALWAYS LET COVER COOL** on a dry, heat-resistant surface before handling. Do not place it on cold or wet surfaces, as this may cause it to crack or shatter.
- **ALWAYS USE POT HOLDERS OR OVEN MITTS** when removing the hot cover. To avoid burns from escaping steam, always tilt cover away from hands and face.

HOW TO USE

Using a slow cooker is easy but different from conventional cooking. This manual contains many helpful hints for successful slow cooking. Many more slow cooker recipes books are available in libraries, bookstores and online. Keep these materials handy whether preparing favorite recipes or trying something new.

This slow cooker has two heat settings: LOW and HIGH. Use the recommended guidelines offered in the recipe being used to determine cooking time and heat setting. Dishes can be prepared well in advance of mealtime and cooking time regulated so that food is ready to serve at a convenient time. A general rule of thumb for most slow cooker meat-and-vegetable combos is:

Cooking Time in Recipes:	Recommended Temperature Setting
8-10 Hours	LOW
4-6 Hours	HIGH

Other favorite recipes may be adapted to the slow cooker. All times listed below are approximate and should serve only as cooking guidelines.

Regular Cooking Time	Slow Cooker Cooking Times	
30 minutes	LOW	HIGH
35-60 minutes	6-8 hrs.	3-4 hrs.
1-3 hours	8-10 hrs.	5-6 hrs.
	10-12 hrs.	7-8 hrs.

1. Prepare recipe according to instructions.
2. Place food in stoneware insert and cover with glass lid.
3. Plug slow cooker into wall outlet and select LOW or HIGH.
4. When food is ready to be served, turn slow cooker OFF and unplug it from outlet.
5. Remove glass lid.

CAUTION: When removing glass cover, grasp the designated area on the cover and lift to allow steam to escape **before setting cover aside. To avoid burns, always hold cover so that escaping steam flows away from hands and face.**

6. Using oven mitts, grasp stoneware insert by the handles and remove it from the heating base. NEVER place insert directly on a counter top. Use a heat-resistant trivet or pad.
7. Serve contents. If serving directly from the cooking pot, always place a trivet or protective padding under pot before placing it on a table or counter top.

USER MAINTENANCE INSTRUCTIONS

This appliance contains no user serviceable parts. Do not try to repair it yourself. Refer it to qualified service personnel if servicing is needed.

PRECAUTIONS

- **Always turn knob to the OFF position, unplug slow cooker power cord from wall outlet and allow to cool before cleaning.**
- Always handle stoneware insert carefully and glass lid. Avoid hitting pot against faucet or hard surfaces.
- Do not touch sides of slow cooker base while food is cooking. Always use handles on the base. Use pot holders or oven mitts to lift the stoneware insert.

TO CLEAN:

This appliance should be cleaned after every use.

After slow cooker has been allowed to cool, wash stoneware insert and glass cover in warm, soapy water. Rinse well and dry. If food sticks to the surface of the stoneware insert, fill the insert with warm, soapy water and allow it to sit for a few hours before cleaning.

Wipe interior and exterior surfaces of the base with a soft, slightly damp cloth or sponge.

NEVER IMMERSE THE BASE IN WATER.

NEVER USE ABRASIVE CLEANSERS OR SCOURING PADS TO CLEAN THE STONEWARE INSERT OR BASE, AS THESE CAN DAMAGE THE SURFACES.

Dishwasher Cleaning

Stoneware insert may be cleaned in an automatic dishwasher. To prevent damage, position it in rack so that it will not hit other items during cleaning.

Special Cleaning

If stoneware insert becomes stained, clean with a non-abrasive cleanser or apply a paste of baking soda with a soft cloth. To remove water spots or mineral deposits, wipe with distilled white vinegar, or pour a small amount into the stoneware insert and let it soak. After cleaning, wash insert in warm, soapy water, rinse and dry.

TO STORE:

Be sure all parts are clean and dry before storing. Store appliance in its box or in a clean, dry place. Never store it while it is hot or wet. To store, place stoneware insert inside the heating base and the cover over the insert. Never wrap cord tightly around the appliance; keep it loosely coiled.

USING THE 20 OUNCE MINI CROCK

The 20 ounce mini crock is intended to heat, hold and serve your favorite cheeses, dips and appetizers at the ideal temperature. The 20 ounce pot should **NOT** be used to cook foods. It will not cook meats, so any food contents should be fully cooked before placing them in the mini crock.

1. Fill the 20 ounce mini crock with the desired dip. The capacity of this pot is 16 to 20 ounces.
2. Plug the power cord into the wall outlet. The heating base will start to warm up.
3. Heat the contents until they are fully melted and hot, stirring occasionally. Depending on capacity, this should take 30-75 minutes.
4. Serve and enjoy. Food should stay warm for up to 4 hours. **TIP:** Keeping the lid on the mini crock will help retain the heat and keep the food at the ideal temperature.
5. When finished using, unplug the power cord from the wall outlet and allow the mini crock to cool. Check contents often so they do not overheat. Never leave mini crock plugged in when empty or nearly empty.

To Clean the 20 Ounce Mini Crock: Never immerse in water or any other liquid. Always unplug before cleaning.

1. Remove the stoneware insert from the heating base and empty the contents of the mini stoneware insert. Fill stoneware insert with water to loosen any left over food and clean thoroughly.
2. Do not use abrasive cleaners or harsh chemicals.
3. Wipe the exterior of the product with a soft, damp cloth.

ONE YEAR LIMITED WARRANTY

SELECT BRANDS, INC. warrants, subject to the conditions stated below, that from the date of purchase, this product will be free from mechanical defects for a period of one (1) year. SELECT BRANDS, INC., at its option, will repair or replace this product found to be defective during the warranty period. Should this product become defective by reason of improper workmanship or material defect during the specified warranty period, Select Brands, Inc. will repair or replace the same effecting all necessary parts replacements for a period of one year from the date of purchase.

Transportation charges on parts, or products in whole, submitted for repair or replacement, under this warranty, must be borne by the purchaser.

CONDITIONS: This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. This warranty does not apply to product sold by third party resellers. Keep the original sales receipt. Proof of purchase is required to obtain warranty service or replacement. Dealers, service centers, or retail stores do not have the right to alter, modify or in any way, change the terms and conditions of this warranty.

Warranty registration is not necessary to obtain warranty on Select Brands, Inc. products. Save your proof of purchase receipt.

ABOUT YOUR PRODUCT WARRANTY: Most warranty repairs are handled routinely, but sometimes requests for warranty service may not be appropriate. For example, warranty service would NOT apply if the product damage occurred because of misuse, lack of routine maintenance, shipping, handling, warehousing or improper installation. Similarly, the warranty is void if the manufacturing date or the serial number on the product has been removed or the equipment has been altered or modified. During the warranty period, the authorized service dealer, at its option, will repair or replace any part that, upon examination, is found to be defective under normal use and service.

NORMAL WEAR: This warranty does not cover normal wear of parts or damage resulting from any of the following: Negligent use or misuse of the product; Improper voltage or current; Use contrary to the operation instructions; Deviation from instructions regarding storage and transportation; Repair or alteration by anyone other than SELECT BRANDS, INC. or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes.

SELECT BRANDS, INC. shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

HOW TO OBTAIN WARRANTY SERVICE: You must contact SELECT BRANDS, INC. Customer Service at 1-913-663-4500. A Customer Service representative will attempt to resolve warranty issues over the phone. If telephone resolution is not possible, the Customer Service representative will require your assistance in performing routine diagnostic procedures. This warranty is effective for the time periods listed above and subject to the conditions provided for in this policy.

Made in China
042519